

Application Details:

Horizontal Application:

Once the blinding concrete on the foundation surface is cleared of foreign materials, Bonus Proof is applied to the ground in a staggered manner. The self-adhesive seams are lightly heated with a torch and bonded using 10-12 kg rollers. Once the bonding cools, the reinforcement steel can be installed without delay.

Vertical Application:

It is applied to the waterproofing surface created in front of the pile walls. The waterproofing surface can be prepared with materials like concrete, brick-block, OSB, or plywood. XPS, a drainage board, and Bonus Proof EP300 V are placed in sequence. Overlaps of 15 cm horizontally and 10 cm vertically are left for bonding, and it is fixed in place with a compression bar from above.